


TM315 SERIES (12.5" diameter)



CROSS SECTIONAL & PARTS DESCRIPTION



ITEM	PART DESCRIPTION	ITEM	PART DESCRIPTION	ITEM	PART DESCRIPTION	ITEM	PART DESCRIPTION
1	Shell	18	Gasket	38	Ball Bearing	55	Backstop Bearing (Optional)
2A	End Flange	20	Terminal Board	39	Needle Bearing	57	Data Plate
2B	End Flange	23	Fillister head Machine Screw	41	Disc	58	Epoxy Resin
3NC	Gear Housing	24	Fillister head Machine Screw	42	Snap Ring		
4NC	Motor Flange	24 A	Lock Washer	43	Snap Ring		
6	Shaft End	27	Set Screw	44	Snap Ring		
7	Hollow Shaft	29	Key	45 A	Bearing race		
8 Z	Internal Gear	31	Socket Head Cap Screw	45 B	Bearng race		
9/10	Pinion With Bushing	32	Socket Head Cap Screw	45 C	End Plate		
11	Gear	33	Socket Head Cap Screw	46	Cassette Seal		
12	Distance Ring	34	Filler Plug	50	Seal		
13WN	Stator	35	Washer	51	Junction Box		
14	Rotor	36	Ball Bearing	52	Junction Box Cover		
15	Socket Head Cap Screw	36V	Cylindrical Roller Bearing	53	Plug		
16	Nitrile Gasket	37	Ball Bearing	54	Key (Optional)		